Stressless® Wing Office



THE INNOVATORS OF COMFORT™

Stressless® Wing Office

Chair, W: 29½” H:43”- 45½” D: 28”
Seat height: 17¼”- 20”

The headrest adjusts automatically, so you can read and watch TV, even in a reclining position.

The Plus™ system adjusts the lower back support simultaneously with the headrest. Upright or reclined, you’re always perfectly supported.

Lower the headrest to the sleep position with one simple movement.

Adjust the Stressless® Glide wheels to the setting of your desire. You can automatically shift to any seating position simply by using your body weight.

Comfort Zones™ give you a better seating comfort, as the indentations let you sink deeper into the seat and back of the recliner.



Your Stressless® Office chair can easily and smoothly be height-adjusted by using the handle under the seat.

The base with wheels is carefully developed and designed to give optimal stability and freedom of movement.